



Example exhaust system installation

The basic version of the installation kit contains the following components for the cooling water, exhaust gas, and fuel installations:

Cooling water installation

- Through-hull with filter
- Seacock
- Hose connection
- Sea water filter
- Hose clamps
- Coolant hose (4m)
- Ventilation valve

Cooling water installation



Exhaust installation

- Water collector
- Hull outlet
- Hose connection
- Hose bush
- Hose clamps
- Exhaust hose (5m)
- Silencer (optional)

Exhaust installation



Fuel installation

- Fuel hose
- Hose clamps
- Non-return valve
- Fuel filter with water separator (optional)
- Fuel quick-release fasteners (optional)

Fuel installation





Installation kit
Basic version

Basic version installation kits

The basic version installation kits contains the following components:

Cooling water installation

- Through-hull with filter
- Seacock
- Hose connection
- Sea water filter
- Hose clamps
- Coolant hose (4m)
- Ventilation valve

Exhaust installation

- Water collector
- Hull outlet
- Hose connection
- Hose bush
- Hose clamps
- Exhaust hose (5m)
- Silencer

Fuel installation

- Fuel hose
- Hose clamps
- Non-return valve

Installationskit Basis-Version ohne Abgas-Wasser-Trenneinheit

21.03.04.046	Installation Kit Panda 4500 ohne Trenneinheit Version 1
21.03.04.080	Installation Kit Panda 4000s, 5000-15000 / AGT 4000-AGT 14000 PMS ohne Trenneinheit Version 1
21.03.04.055	Installation Kit Panda 18-24 / AGT 15000-16000 PMS ohne Trenneinheit
21.03.04.018	Installation Kit Panda 50 YA PMS ohne Trenneinheit
21.03.04.016	Installation Kit Panda 30 / AGT 25000 PMS ohne Trenneinheit
21.03.04.029	Installation Kit Panda 60/4 PMS ohne Trenneinheit



Installation kit
Premium version

Premium version installation kits

All components of the basic version plus exhaust/water separator to reduce exhaust noise

Installationskit Premium-Version

21.03.04.056	Installation Kit Panda 4500 mit Trenneinheit Version 2
21.03.04.057	Installation Kit Panda 4000s, 5000-15000 / AGT 4000-AGT 14000 PMS mit Trenneinheit Version 2
21.03.04.067	Installation Kit Panda 18 - 24 / AGT 15000-16000 PMS mit Trenneinheit
21.03.04.017	Installation Kit Panda 30 / AGT 25000 PMS mit Trenneinheit
21.03.04.019	Installation Kit Panda 50 PMS mit Trenneinheit
21.03.04.021	Installation Kit Panda 60/4 PMS mit Trenneinheit
21.03.04.028	Installation Kit Panda 65 PMS mit Trenneinheit